

Foot Tracing Procedure for Rilleau Custom Sandals

POINTERS:

- Use lightweight cardboard (file folder thickness or thereabout). A pencil or pen will do, but if available a "grease crayon" or china marker is better.
- Have the cardboard on a smooth, firm surface. Trace one foot at a time, keeping about two thirds of the weight on the foot being traced.
- Having someone else do the tracing makes it easier, especially around the heel.

STEPS:

- Keeping the pencil or crayon as straight up and down as possible, trace the outline of the foot. Don't trace between the toes, but do trace a line between the big and second toe as far into the crotch as you can. Please be extra careful when tracing around the heel to keep the pen straight up and down, especially if you're doing it yourself.
- Then trace a line as deeply under the arch as you can, from the base of the big toe going back toward the heel (this is where a crayon can give an easier line to read). The higher an arch one has, the greater the line will be "scooped" or arched.
- Be sure to trace both feet.
- You can refer to the sample tracing (next page) although of course feet will vary from the example given.

